

► HV ESSENTIAL 4V6

o Working jacket

size [cm]	М	L	XL	2XL	3XL
А	72	74	76	78	80
С	58	62	66	70	74
Н	63	64	65,5	67	68,5

All size specifications listed are in cm. Accepted tolerance of up to \pm - 5%.

